



SPORTSMAN

Installation Instructions

Part # XG - 301

STEP 1: Remove all components from packaging and spread out in cargo area of Jeep.

STEP 2: Attach all three (3) top Velcro straps as shown around roll bar.



STEP 3: Attach metal side clips to side rails of Jeep. Center Sportsman and tighten straps securely. Sportsman must be tight from side-to-side to prevent pets from squeezing between windows/sides and Sportsman.

STEP 4: Attach all three (3) plastic latch hooks to floor connections and tighten securely. Do not overtighten these straps. They are designed to hold the Sportsman in position only.

WARNING!

The Sportsman pet barrier/organizer is a soft-sided sewn product and not a metal barrier. It is not intended for use with disobedient pets. Please be sure your pets are capable of obeying commands to stay in the rear of the vehicle at all times.

User is responsible for removing or securing gear, goods and food stuff before transporting pets. User is responsible for securing pet or pets in vehicle prior to and when vehicle is in motion. User responsible for securing Sportsman in place prior to operating vehicle. Follow all traffic laws and be sure to avoid overfilling pockets of Sportsman.