



ORACLE LIGHTING

FORD BRONCO DASH KIT

ORACLE PART #4237-332

INSTALLATION GUIDE

TOOLS NEEDED:
PANEL TOOL
T-30 TORX BIT
SOCKET WRENCH
ALCOHOL PREP PAD
SCISSORS



SCAN TO VIEW INSTALL VIDEO

BEFORE DIVING INTO THE INSTALL WE RECOMMEND WATCHING OUR INSTALLATION VIDEO FIRST. SCAN THE QR CODE ABOVE.



THE IMAGE ON THE LEFT SHOWS THE BOTTOM LED STRIP INSTALLED. THE AREA HIGHLIGHTED IN RED INDICATES WHERE WE APPLIED THE 3M ADHESIVE BACKING. WE RECOMMEND PLACING THE ADHESIVE DIRECTLY ONTO THE DASH SURFACE FOR SECURE MOUNTING OF THE BOTTOM STRIP. NOTE THAT THE EDGE NEAR THE HANDLE WILL NEED TO BEND SLIGHTLY UPWARD TO FOLLOW THE CONTOUR OF THE DASH PROPERLY.



IN THIS IMAGE, YOU CAN SEE WHERE THE STRIP BEGINS TO LIFT FROM THE TRIM SURFACE, BENDS UPWARD, AND IS INSERTED BETWEEN THE TRIM PIECE AND THE DASHBOARD FOR A SEAMLESS FIT.

FOR THE UPPER STRIP, WE LEFT THE 3M ADHESIVE BACKING IN PLACE DURING INSTALLATION. THE ADDED THICKNESS HELPED SECURE THE STRIP BETWEEN THE DASH AND THE UPPER TRIM PIECE. ONCE POSITIONED CORRECTLY, WE PEELED OFF THE 3M BACKING TO ADHERE IT IN PLACE. TIP: ENSURE THE ILLUMINATED EDGE OF THE STRIP IS NOT PUSHED TOO FAR BEHIND THE UPPER TRIM, THIS KEEPS THE GLOW VISIBLE AND EVENLY DISTRIBUTED.

INSTALLATION STEPS:

STEP 1: LOCATE THE PASSENGER-SIDE DASH HANDLE. USING A T-30 TORX BIT AND SOCKET WRENCH, REMOVE THE FOUR (4) T-30 TORX SCREWS TO RELEASE THE HANDLE.

STEP 2: OPEN THE GLOVE BOX. DEPRESS THE TWO (2) INNER TABS TO RELEASE IT FROM THE DASH.

STEP 3: LIFT UP TO DISENGAGE THE HOOKS, THEN GENTLY PULL THE GLOVE BOX OUTWARD TO REMOVE IT.

STEP 4: USE THE INCLUDED PANEL TOOL TO DETACH THE LOWER DASH TRIM PANEL. BEGIN FEEDING THE LED STRIP WIRES THROUGH THIS OPENING. TIP: DISCONNECT THE STRIP ENDS FROM THE USB ADAPTER FOR EASIER ROUTING.

STEP 5: ROUTE THE LED STRIP WIRES BEHIND THE CENTER DASH STRUCTURE AND GLOVE BOX AREA AS SHOWN IN THE IMAGE.

STEP 6: INSTALL THE SHORTER LOWER DASH LED STRIP BY FEEDING IT BEHIND THE GLOVE BOX AND THROUGH THE DESIGNATED OPENING INDICATED IN THE IMAGE.

STEP 7: INSTALL THE LONGER UPPER DASH LED STRIP IN THE SAME MANNER, ROUTING IT BEHIND THE GLOVE BOX AND THROUGH THE MARKED UPPER LOCATION.

STEP 8: REFER TO THE CLOSE-UP IMAGE FOR EXACT WIRE ROUTING LOCATIONS AND STRIP ENTRY POINTS TO ENSURE A CLEAN, FACTORY-STYLE INSTALLATION.

STEP 9: PREPARE THE REAR SURFACE OF EACH LED STRIP WITH THE AN ALCOHOL PREP PAD TO ENSURE OPTIMAL ADHESIVE BONDING.

STEP 10: APPLY THE PROVIDED 3M ADHESIVE TAPE TO THE BACK OF EACH LED STRIP.

STEPS 11-14: USING THE PROVIDED PANEL TOOL, BEGIN INSERTING THE STRIPS INTO THE SEAMS ALONG THE DASH EDGES. FEED THE STRIPS ALONG THE CONTOURS TOWARD THE STEERING WHEEL. USE THE 3M ADHESIVE TO SECURE SECTIONS WHERE NEEDED. FINAL STRIP EDGES SHOULD ALIGN AS SHOWN IN IMAGES 13 AND 14. NOTE: THIS STEP MAY REQUIRE SOME FINESSE DEPENDING ON YOUR BRONCO'S TRIM. REFER TO THE IMAGES ABOVE FOR ASSISTANCE.

STEP 15: CONNECT THE LED STRIPS TO THE USB POWER ADAPTER. SWITCH THE VEHICLE TO ACCESSORY MODE AND PRESS THE POWER BUTTON ON THE ADAPTER TO ACTIVATE. YOU CAN CONTROL THE KIT USING THE BUILT-IN POWER BUTTON, THE INCLUDED RF REMOTE, OR THE FREE LED LAMP APP (SELECT "LED-DMX00-XXX" IN THE APP TO PAIR YOUR KIT).

STEP 16: REINSTALL ALL REMOVED VEHICLE COMPONENTS BY REVERSING THE DISASSEMBLY STEPS.

FLIP FOR IMAGES →



www.oraclelights.com

© 2025 ORACLE LIGHTING

4401 Division St.
Metairie, LA 70002

FOR ADDITIONAL TECHNICAL SUPPORT PLEASE CALL US 1(800)407-5776

