



INSTALLATION INSTRUCTIONS

PART No.

FB21316

**Fits: Fishbone Offroad Tackle Racks
Tackle Rack Bike Mount Brackets**



Cam-Lock NOT included

REQUIRED TOOLS

19mm Socket

KIT CONTAINS

- Cam-Lock Mount
- Wheel Chock Mount
- M12 Carriage Bolt
- M12 Hex Nut
- M12 Lock Washer
- M12 Carriage Bolt Washer
- Nylon Strap

QTY

- 1
- 1
- 4
- 4
- 4
- 4
- 1

2131600

**Fits: Fishbone Offroad Tackle Racks
Tackle Rack Bike Mount Brackets**

1) MEASURE YOUR BIKE

Begin by measuring your bike from the center of your front forks to rear wheel.



Decide which side of your rack you wish to install your bike and lay out the measurement onto the rails.

2) INSTALL THE BRACKETS

Starting with the Cam-Lock Mount, install your Cam-Lock of choice according to the manufacturer's instructions.



Install the mount by lining up the carriage bolt holes onto your rails, and secure it with the included carriage bolts, carriage washers, lock washers, and hex nuts (in that order) with a 19mm socket.

Note: If you wish to add more rigidity to the mount, you may install the Cam-Lock Mount to an arch by sharing the carriage bolts that secure the rail.



Install your wheel chock bracket with the remaining hardware at your second measurement.



3) MOUNT YOUR BIKE

Remove your bicycle's front wheel, and secure it to your installed Cam-Lock.

Raise the rear wheel and place it into the wheel chock, and secure it with the included Nylon strap.