

INSTALLATION INSTRUCTIONS

PART No.

FB33192R

2018 – Current JL Wrangler

Aluminum RAW Rear Inner Fenders



REAR



REQUIRED TOOLS

3mm Allen

RECOMMENDED TOOLS

KIT CONTAINS

Rear Inner Fender Set (Driver/Passenger)

QTY

1

Rear Set:

20mm Button Head Bolt

6

10mm Washer

6

1) PREPARE YOUR VEHICLE

Remove your vehicle's existing inner and outer fenders. Please visit Fishbone Offroad on YouTube for instructions on how to remove your OEM parts.



Within the driver side rear well, and with a 10mm socket, remove your fuel filler neck bracket bolt.



Gently pull the neck loose and push it down below the stud. The passenger side doesn't need to be changed.



Note: The mesh and accent plates can be removed with a 3mm Allen key to be painted separately.

2) INSTALL YOUR REAR FENDERS

Secure the fender with a 3 20mm bolts and 10mm washers behind the body.



Tighten all visible bolts with a 3mm Allen key.

Repeat on the opposite side.

3) ENJOY YOUR NEW FISHBONE OFFROAD ALUMINUM INNER FENDERS!