



# INSTALL SHEET

## JLRCM18, ROLL CAGE MOUNT

### 2018 JEEP WRANGLER JL

**VIDEO GUIDES:**  
[WWW.MCAFTERMARKET.COM/INSTALL](http://WWW.MCAFTERMARKET.COM/INSTALL)

PACKAGE CONTAINS



ID: JLRCM18.062819

### SERVICE AND SUPPORT

## CONTACT

**Motor City Aftermarket**  
**734-525-9030**  
**[sales@mcaftermarket.com](mailto:sales@mcaftermarket.com)**  
**[www.mcaftermarket.com](http://www.mcaftermarket.com)**

1

Remove the top of your Jeep.  
Lubricate the tap with a generous amount of WD-40. Next, insert the tap, which we include, into a T-Style Hand Tap Tool. Insert the tap making sure that it is perpendicular. The tap must go straight into the hole.

2

Begin turning the tap clockwise into the hole. Keep the tap perpendicular to the roll cage as you slowly turn the tap into the hole. Turn the tap until you're 1.5" deep into the hole. Slowly back the tap out of the hole. Carefully blow the metal shavings from the area. It may be necessary to turn the tap back into the hole to make sure the threads are clear.

3

Once the threads are clear and the shavings have been blown out of the way, pre-fit the mounting bolt into the newly tapped hole. The bolt should fit without issue. If you do run into resistance you can always reinsert and then turn the tap back into the hole to clear any rough spots.

4

You're clear to mount the bar. In order for the soft top to clear the mounting bar, be sure to mount the bar so that the center section is closest to the rear of the vehicle. Be sure to use a washer on both sides of the mounting Fully tighten both bolts and you're off and running.

