



Installation Instructions

TAILGATE ACCESSORY PANEL

For the '07-'18 JK/JKU Wrangler

1. Remove the factory cover panel by pulling out on the left side until the clips release. Pull on the top left to release the top clip; pull on the bottom left to release the bottom clip.



2. Slip the clip-nuts over the holes the clips came out of.



3. Insert two screws into the right side holes in the panel and thread them into the holes in the aluminum backing plate. The backing plate should be installed so the edge of the plate lines up with the edge of the panel.

4. Slip the aluminum backing plate behind the right edge of the hole in the tailgate and align the panel over the opening.



5. Insert two screws into the holes in the left side of the panel and screw them into the clip nuts you installed in step 2.

6. Finally, tighten the two screws on the right side of the panel. They should be snug, but do not overtighten them.

