Quadratec® Replacement LED Tail Lights & Flashers


Installation Manual: Tail Lights and Flasher Control Units #55213.XXXX



PARTS LIST:

LED Replacement Tail Lights - QTY 2 Replacement/Trailering Flasher - *QTY 1 *Varies by Year and Model **REQUIRED TOOLS:**

Safety Glasses Phillips Head Screwdriver 3/8" Socket & Ratchet Driver






A Few Words About Product Safety:

Your Tail Lights are intended to enhance the looks and visibility of your off road capable vehicle. Before installation, please take a moment to review the following safety information

and installation instructions. Important safety information is generally preceded by one of three signal words indicating the relative risk of injury. The signal words mean:



Before You Begin Installation:

Congratulations on your purchase of Quadratec LED Style Replacement Tail Lights. Because of the similarity of the taillight design over several generations of Jeep Vehicles, this set of instructions covers installation of several different years and models. The installation of the flasher control unit varies by generation of Jeep vehicle. Always verify the location of all electrical components in your vehicle's original owner's manual. These instructions are meant as a guide but some component locations and wiring can vary between vehicle production dates and model years. These LED Compatible Flasher also doubles as a Heavy Duty Trailering Flasher. This allows proper flasher operation with most trailer lights.

Please check to make sure all parts are included and not damaged due to shipping. If any part is missing or broken, please call Customer Service at 800-745-6037 as soon as possible. Thank you again for your purchase.



Flasher Solenoids: (vary by model)

for '96-'00

Early TJ







for '76-'95 YJ & CJ

for '01-'06 Later TJ



Tail Light Installation:



Before you begin installation, put on safety glasses. Start by removing 4 phillips screws.



Remove tail light lens as shown in figures 1 and 2.



Figure 3: Remove the 3 socket headed screws that attach the taillight to the body of the vehicle using a 3/8" socket.




Figure 4: Gently pull the light housing away from the body.



The Trusted Source

Tail Light Installation:



Unplug the taillight harness from the vehicle wiring harness. It may be necessary to remove tape from this connection first. The plug on your harness may look different from version shown here.



On some vehicles it may also be necessary to reach up in to the wheel well behind the taillight in order to access the harness connector.



New Tail Light Installation:

Installation is the reverse order of the steps above. Remove the 4 screws and lens on your new Quadratec LED taillight. Plug your new Quadratec LED taillight into the vehicle wiring harness.

Install the new taillight to the vehicle using the original factory screws. Install the screws by hand and then snug the screws using a 3/8" socket.

Note: Be careful not to pinch any wiring when tightening the screws. Reinstall the lens and the 4 screws. The tail light install is now complete.

ACAUTION A

ALWAYS CHECK TAIL LIGHT FUNCTION BEFORE DRIVING!



The Trusted Source

Flasher Installation for '01-'06 Wrangler (Late TJ)



Remove 2 Phillips screws on the bottom of the steering column. Lower the tilt



steering wheel if equipped. Remove plastic upper steering column cover.



Locate Flasher Assembly. Remove the original factory flasher. Take note of the pin orientation for



installation of the new flasher module. Orient flasher blades as shown and install the new Flasher module. Test the



turn signals and flashers. Reinstall Cover. Make sure to align rubber stalk boots in the groves on the upper and



lower steering column covers, and lastly replace the (2) phillips head screws under the steering column (see Fig.8)



The Trusted Source


Flasher Installation for '97-'00 Wrangler (Early TJ)



First, remove 2 phillips screws from lower dash panel and remove the plastic




trim panel to expose the metal shield.



Remove 4 socket headed screws with a 7mm socket from the metal shield.



or wiring loom. Remove Relay from the retaining bracket and unplug it from the wiring harness. Plug in new Relay and clip it back into the retaining bracket or securely fasten it using a cable tie. Test



Locate the factory flasher unit. It may be partially hidden behind a hose



turn signals and hazard flashers. Reinstall the metal shield with the 4 factory fasteners. Finally, reinstall the plastic lower dash panel with the (2) Phillips screws from Fig.14.



The Trusted Source

Flasher Installation for CJ & '87-'95 YJ Wrangler




Locate the fuse panel in the driver side foot well of the vehicle. Identify the round Turn Signal Flasher in the upper right of the fuse panel. In most cases the factory flasher is light blue in color.



There is a second flasher unit that is used for the hazards. This is the unit on the left. Do not replace this unit. Remove only the right hand flasher and install new replacement.



In some CJ models the Turn Signal relay is not located in the Fuse panel. The relay is hanging in a separate harness under the dash near the fuse panel. In most cases, if it is the original it should be blue in color.



Remove the relay and replace it with the new LED compatible relay.

Test the turn signals right away. If operation is normal, installation is complete.



Quadratec[®] Exclusive Three Year Limited Warranty

Your Quadratec[®] branded accessories are covered by the following **Limited Warranty** provided exclusively by Quadratec, Inc., 1028 Saunders Lane, West Chester PA 19380.

This **Limited Warranty** is the only warranty made in connection with your purchase. Ouadratec neither assumes nor authorizes any vendor, retailer or other person or entity to assume for it any other obligation or liability in connection with this product or **Limited Warranty**. This **Limited Warranty** does not apply and is not cumulative to any accessory or part distributed by Ouadratec for which the Manufacturer provides a separate written warranty.

What is Covered: Subject to the terms, exclusions and limitations herein and with respect only to Quadratec branded accessories first sold in the United States, Quadratec warrants to the initial retail purchaser only that your Quadratec accessory shall be free of defects in material and workmanship: for a period of three (3) years from date of retail purchase.

This **Limited Warranty** is not assignable and shall terminate upon sale of the vehicle upon which the Quadratec accessory is installed or other transfer third persons.

All other warranties are hereby disclaimed, except to the extent prohibited by applicable law in which case any implied warranty of merchantability or fitness for a particular purpose on this product is limited to 3 year from date of initial retail sale. Quadratec reserves the rights to: (a.) require invoice or other proof your accessory is within the terms of this **Limited Warranty** as a condition of warranty service and, (b.) make future revisions to this product and **Limited Warranty** without prior notice or obligation to upgrade your product.

What is Not Covered:

Your Quadratec **Limited Warranty** does not cover products or parts Quadratec determines to have been damaged by or subjected to: (a.) installation damage, alteration, modification, combination with other parts, failure to maintain or improper repair or service, (b.) normal wear & tear, cosmetic damage or damage from moisture or water immersion, (c.) Acts of God, accidents, misuse, negligence, inadequate mounting or impact with vehicle(s), obstacles or other aspects of the environment, (d.) theft, vandalism or other intentional damage.

Remedy Limited to Repair/Replacement: The exclusive remedy provided hereunder shall, upon Quadratec inspection and at Quadratec's option, be either repair or replacement of product or parts (new or refurbished) covered under this Limited Warranty. Customers requesting warranty consideration should first contact Quadratec to obtain a RGA number (610-701-3336). All labor, removal, shipping and installation costs are customer's responsibility.

Other Limitations - Exclusion of Damages -Your Rights Under State Law:

In consideration of the purchase price paid, neither Quadratec nor any independent Quadratec distributor/licensee are responsible for any time loss, rental costs, or for any incidental, consequential, punitive or other damages you may have or incur in connection with any part or product purchased. Your exclusive remedy hereunder for covered parts is repair/replacement as described above.

This **Limited Warranty** gives you specific rights. You may also have other rights that vary from state to state. For example, some states do not allow limitations of how long an implied warranty lasts and /or do not allow the exclusion or limitation of incidental or consequential damages, so the limitations and exclusions herein may not apply to you.

©Quadratec, Inc. 2013. All Rights Reserved. 5.13.15 LTR Version

Part #12999.3009

