

# JKS™

## Installation Instructions



Product: **Slickrock Spring Hangers™**

Part Number: **PN SR101**

Application: **CJ5 / CJ7 / CJ8, 1976-86**

### Welcome

CONGRATULATIONS on your purchase of new JKS Slickrock Spring Hangers! At JKS Manufacturing, we are committed to providing you with the best products available and your satisfaction is our first priority.

PLEASE READ these instructions carefully, as they contain important installation information.

### Important

**REFER TO FACTORY SERVICE MANUAL** for information and procedures not covered in these instructions.

### Tools Required

- Hydraulic Floor Jack & Jack Stands
- Metric/Standard Socket Wrench Set
- Torque Wrench
- Medium Strength Threadlocker \*
- Anti-Seize Lubricant \*
- Factory Service Manual (recommended)

\* Asterisk denotes tools that are not required for some applications. Thoroughly read instructions first to determine which tools will be required for your application.

### Installation

#### 1. PRE-INSTALLATION PROCEDURES

- Raise the front of vehicle and support the chassis with jack stands positioned behind the front leaf springs. Support the axle housing with a hydraulic jack to relieve the axle weight.
- Remove front wheels from vehicle. Front bumper should also be removed if it restricts access to spring hangers.
- Remove the spring shackle hardware from original spring hangers. Retain original mounting hardware for reinstallation.
- Lower the hydraulic jack allowing leaf springs and shackles to drop away from chassis.  
**HINT:** If necessary, disconnect any other components that prevent axle from being lowered. Do NOT over extend brake lines.
- Remove the original shackle bushings and sleeves from spring hangers.

#### 2. REMOVE OE SPRING HANGERS

- Remove the hardware that secures the original spring hangers to the chassis. Discard hangers, but retain the hardware if in good condition.
- With the original spring hangers removed, clean the chassis surface of any debris that may interfere with installation of Slickrock Spring Hangers.

#### 3. MOUNT SLICKROCK SPRING HANGERS TO CHASSIS

- Align the Slickrock Spring Hangers with the original spring hanger mounting holes in chassis.
- Apply medium strength threadlocking compound to bolt threads of original mounting hardware. If condition of original mounting hardware is questionable, replace with new Grade 5 bolts, flat washers, and lock washers and apply anti-seize lubricant instead.
- Secure Slickrock Spring Hangers to chassis with appropriate mounting hardware.
- Tighten Slickrock Spring Hanger mounting hardware to factory specifications using a torque wrench.

#### 4. REINSTALL SPRINGS AND RELATED COMPONENTS

- Install original shackle bushings and sleeves in Slickrock Spring Hangers.  
**HINT:** Install new bushings if original parts are damaged or worn. Polyurethane bushings should be lubricated prior to installation.
- Raise the axle into position and align leaf spring shackles with Slickrock Spring Hangers.
- Secure spring shackles to Slickrock Spring Hangers using original mounting hardware.  
**HINT:** Reconnect any other components that may have been removed to lower the axle.
- Reinstall front wheels. Front bumper should also be reinstalled if it was previously removed.
- Remove the jack stands from beneath chassis and lower vehicle to the ground.
- Tighten all mounting hardware to factory specifications using a torque wrench.

© 2006 JKS Manufacturing, Inc & Aftermarketing, LLC  
Revision Date 5/24/2006