

## Trigger Pedestal Mount Assembly Instructions Part Number 2020

PLEASE READ ALL INSTRUCTIONS AND CHECK TO BE SURE ALL PARTS LISTED ARE INCLUDED BEFORE BEGINNING ASSEMBLY.










If running 12 volt power to the Pedestal, insert the 12 volt power wire included in the original Trigger 6 Shooter packaging (not included with Pedestal Kit). Wire is inserted on one side of the base, then routed through opening as shown.


NOTE: Skip this step if <u>not</u> using 12 volt power to base or if using the 4 Channel Triggers.



Halves are then screwed together with wire inserted. Use the 2.6 mm pan head screws.









Install the 2 screws/washers for the pivot loosely into the pivot hole as shown. Now install the lower half of the main mount (C) being careful to be sure the washers are in the correct location.

Install the upper half of the main mount (D) in place, be sure the pivot screws and washers are in the correct position. Use two 2.8mm screws as shown and tighten.

4








The mounting Foot is designed to use either the included VHB tape or screws (not included) to mount the Pedestal. It can be pre-mounted before the main mount if the location is difficult to reach with the complete assembly or to allow easier access tho the mounting screw locations. It also allows removal of the main assembly without removing the screws or VHB tape as needed.

Slide the Pedestal base assembly into the mounting foot as shown then slide the rear keeper in place to secure the main assembly.

## Pedestal adjustment and pivot detail







Installation of Trigger Mounting Plate
(Use original Trigger 6 Shooter mount included in Trigger
controller kit. Not included in Pedestal Kit)