INSTALLATION INSTRUCTIONS

Part No. 30497

Taillight Guard

Components:

Item QTY Description

A 1 Driver Side Lens Cover B 1 Passenger Side Lens Cover

Hardware:

Item QTY Description

1 6 12 – 24 x 1 ¼" Hex Head Screw

NOTE: Use anti seize compound on stainless steel hardware for ease of removal and installation of product.

Instructions:

- 1. Remove driver side rear tail lens cover with Phillips screwdriver.
- 2. Remove and discard three fasteners securing tail lens housing to vehicle body.
- 3. Pull wire harness connector out of access hole and disconnect.
- 4. Feed tail lens wire harness through hole in driver side tail lens cover.
- 5. Fasten electrical connector.
- 6. Attach light and cover assembly to vehicle using longer bolts supplied.
- 7. Re-install lens.
- 8. Repeat steps 1 through 7 for opposite side.

