



NOTE: due to normal manufacturing processes you may have "flashing" (small fibers of plastic) around the pod holes. Once the instrument(s) are installed in the pod you will not be able to see the "flashing."

5 Gauge Bezel (for 2 1/16" gauges)

1. Remove the stock five gauge console. Keep the screws from the top for the new console.
2. Disconnect the stock gauges.
3. Install and wire gauges in the new console.
4. Install console - use the stock screws in the top three holes and the three provided screws in the lower three holes. Place the stand-offs on the back side of the panel over each of the three screws. (Use tape to hold the stand-off on the screws while installing).

3-3/8 Gauge Bezel

1. Remove screws from around OEM Bezel. Be sure to retain factory screws as they will be reused for the bezel installation.
2. Remove center bezel and separate the two pieces away from steering column. Small center piece above steering column will be reused.
3. Remove factory screws from OEM instrument cluster and disconnect wiring harness.
4. Run necessary wiring and install gauges.
5. Install new bezel utility factory screws.

Auto Meter Gauge Works Three Year Limited Warranty

Gauge Works warrants to the consumer that all Auto Meter Gauge Works products will be free from defects in material and workmanship. Products that fail will be repaired or replaced at Auto Meter Gauge Works' option to the consumer, when determined by Auto Meter Gauge Works that the product failed due to defects in material or workmanship. This warranty is limited to the repair or replacement of parts in the Auto Meter Gauge Works Product and the necessary labor done by Auto Meter Gauge Works to effect the repair or replacement of the Auto Meter Gauge Works product. In no event shall this warranty exceed the original purchase price of the Auto Meter Gauge Works product nor shall Auto Meter Gauge Works be responsible for special, incidental or consequential damages or costs incurred due to the failure of this product. Warranty claims to Auto Meter Gauge Works must be transportation prepaid and accompanied with proof of purchase. This warranty applies only to the original purchaser of product and is non-transferable. Improper use or installation, accident, water damage, abuse, unauthorized repairs or alterations voids this warranty. Auto Meter Gauge Works disclaims any liability for consequential damages due to breach of any written or implied warranty on all products manufactured by Auto Meter Gauge Works. This warranty is made solely by Gauge Works with Auto Meter being the agent to contact for warranty claims. If the partnership between Auto Meter and Gauge Works dissolves, then all warranty adjustments will be covered by the Gauge Works Co.

FOR SERVICE CONTACT: AUTO METER PRODUCTS Inc. 413 W. Elm St., Sycamore, IL 60178 USA (815)899-0801 or

Email us at service@autometer.com