

## **INSTRUCTIONS**

### **EASY SCREW TOP TOOL™**

#### **ALWAYS START THREADING HAND SCREW BY HAND!**

1. For removal of the hand screws that cinch down the front two panels of the three- piece freedom top, install the hexagonal bit end of the Easy Screw Top Tool™ into any ¼” drive cordless screwdriver. DO NOT use the Easy Screw Top Tool™ with any type of drill, cordless or corded.
2. Place the Easy Screw Top Tool™ plastic end into the hand screw where you would normally grasp it with your hand.
3. Making sure that the cordless screwdriver is in reverse, press the button and mechanically remove the screw.
4. For installing the hand screws after replacing the top panels, carefully align the hand screws by hand and turn clockwise until each screw is partially threaded into the receiving threads. ALWAYS start these hand screws by hand to avoid cross threading the screw into the receiving threads.
5. Next, place the Easy Screw Top Tool™ plastic end into the hand screw and complete installation with the cordless screwdriver pressing the forward or clockwise button. Do not over tighten.
6. We recommend that the user only use a cordless screwdriver when installing and removing the hand screws to avoid over tightening or cross threading the screws.
7. In no event shall our company be liable for any direct, indirect, punitive, incidental, special consequential damages, to property or life, whatsoever arising out of or connected with the use or misuse of our products.

3/06/2017