





ORACLE LIGHTING

REVERSE LED MODULES
ORACLE PART # 5915-JL-023
INSTALLATION GUIDE


TOOLS NEEDED:
PHILLIPS SCREWDRIVER




REMOVE THE (9) PHILLIPS SCREWS SECURING THIS BRACKET & REVERSE MODULE IN PLACE.




REMOVE BRACKET FROM TAIL LIGHT.



DISCONNECT REVERSE MODULE FROM TAIL LIGHT HARNESS.




REMOVE REVERSE MODULE FROM TAIL LIGHT.




PLACE IN NEW AMBER/WHITE REVERSE MODULE.



PLUG IN NEW AMBER/WHITE REVERSE MODULE TO TAIL LIGHT HARNESS.



RE-INSTALL BRACKET WITH (9) PHILLIPS SCREWS.



SLIDE NEW YELLOW WIRE INTO PIN 4 ON THE MAIN TAIL LIGHT PLUG.