Quadratec® 7" LED Headlight Installation Brackets

Installation Manual: for Jeep Wrangler ('18 - Current)
JL & JLU Vehicles #97109.020X











PARTS LIST:

Headlight Brackets - QTY 2 H13 to JL Wiring Harnesses – QTY 2 Pulse Width Modulation (PWM) or

Wiring Harness - QTY 2 (Quadratec GEN II Headlamps ONLY)

REQUIRED TOOLS:

Safety Glasses 10mm Socket, Extension & Ratchet 4mm Hex/Allen Wrench Key Phillips Head Screwdriver Small Flat Blade Screwdriver

ACAUTION A


READ ALL SAFETY MESSAGES AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING TO INSTALL THIS PRODUCT. ALWAYS WEAR SAFETY GLASSES DURING INSTALL.



Headlight Brackets Installation for '18 - Current JL Wrangler



Put on safety glasses. Open the hood of your Jeep®. Put the prop rod into the correct slot to hold hood open (FIG 1).



Locate the six plastic fasteners that secure the front grille to the upper body support (FIG 2).



Pry up the plastic fasteners (6 total) using a small flat blade screwdriver. First remove the center, then remove the body of each plastic retainer (FIG 3). Set rivets aside in a safe place for re-installing the grille.



Gently tilt the grille forward and then gently pop the lower portion of grille from its (8) retaining clips. (FIG 4).



The Trusted Source

Headlight Brackets Installation for '18 - Current JL Wrangler



Remove the original headlights using a 10mm socket. Save hardware. (FIG 5)



Disconnect the headlights by depressing the black latch & pull outward. (FIG 6)




Connect the JL adapter harness to the vehicle harness. You will hear a "click" when fully engaged (FIG 7)



Connect the PWM harness to the JL adapter harnesses, you will hear a "click" when fully engaged. (FIG 8)



On your new headlight brackets, remove the 3 screws holding the trim ring using a Phillips head screwdriver. (FIG 9)




Lay your headlights in place, making sure they are lined up with the notches in the bracket and secure using the trim ring and 3 Phillips head screws. (FIG 10)



The Trusted Source

Headlight Brackets Installation for '18 - Current JL Wrangler







Connect the new LED headlight harness to the other connector on the Pulse Width Modulation (PWM) Harness (FIG 13A) or JL adapter harness. (FIG 13B)



On the Premium LED Projector Beam Headlights you will hear an audible "click" when connector is fully engaged.



Carefully stow the wiring and or PWM into the headlight bucket area. Be careful not to pinch any wires. (FIG 12)





Align the three tabs on the headlight bracket with the vehicle and install using the 3 original bolts. (FIG 13)



The Trusted Source

Headlight Brackets Adjustment:





Always check the aim of your headlights before driving and adjust as needed using a 4mm Hex/Allen Wrench Key on the adjusting screws. (FIG 14) Note: If you need to aim them down use only the lower 2 adjustment screws. For upward adjustment use only the top center screw.

Reinstall the Grill in the reverse order of the disassembly. (FIGS 4,3, &2)

JL installation is complete.





ACAUTION A

ALWAYS CHECK TURN SIGNAL AND HEADLIGHTS FUNCTION BEFORE DRIVING AFTER HEADLIGHT AND GRILLE INSTALLATION.



The Trusted Source

Quadratec® Exclusive Three Year Limited Warranty

Your Quadratec® branded accessories are covered by the following **Limited Warranty** provided exclusively by Quadratec, Inc., 1028 Saunders Lane, West Chester PA 19380.

This Limited Warranty is the only warranty made in connection with your purchase. Quadratec neither assumes nor authorizes any vendor, retailer or other person or entity to assume for it any other obligation or liability in connection with this product or Limited Warranty. This Limited Warranty does not apply and is not cumulative to any accessory or part distributed by Quadratec for which the Manufacturer provides a separate written warranty.

What is Covered: Subject to the terms, exclusions and limitations herein and with respect only to Quadratec branded accessories first sold in the United States, Quadratec warrants to the initial retail purchaser only that your Quadratec accessory shall be free of defects in material and workmanship: for a period of three (3) years from date of retail purchase.

This **Limited Warranty** is not assignable and shall terminate upon sale of the vehicle upon which the Quadratec accessory is installed or other transfer third persons.

All other warranties are hereby disclaimed, except to the extent prohibited by applicable law in which case any implied warranty of merchantability or fitness for a particular purpose on this product is limited to 3 year from date of initial retail sale. Quadratec reserves the rights to: (a.) require invoice or other proof your accessory is within the terms of this Limited Warranty as a condition of warranty service and, (b.) make future revisions to this product and Limited Warranty without prior notice or obligation to upgrade your product.

What is Not Covered:

Your Quadratec **Limited Warranty** does not cover products or parts Quadratec determines to have been damaged by or subjected to:

(a.) installation damage, alteration, modification, combination with other parts, failure to maintain or improper repair or service, (b.) normal wear & tear, cosmetic damage or damage from moisture or water immersion, (c.) Acts of God, accidents, misuse, negligence, inadequate mounting or impact with vehicle(s), obstacles or other aspects of the environment, (d.) theft, vandalism or other intentional damage.

Remedy Limited to Repair/Replacement:
The exclusive remedy provided hereunder shall, upon Quadratec inspection and at Quadratec's option, be either repair or replacement of product or parts (new or refurbished) covered under this Limited Warranty. Customers requesting warranty consideration should first contact Quadratec to obtain a RGA number (610-701-3336). All labor, removal, shipping and installation costs are customer's responsibility.

Other Limitations - Exclusion of Damages - Your Rights Under State Law:

In consideration of the purchase price paid, neither Quadratec nor any independent Quadratec distributor/licensee are responsible for any time loss, rental costs, or for any incidental, consequential, punitive or other damages you may have or incur in connection with any part or product purchased. Your exclusive remedy hereunder for covered parts is repair/replacement as described above.

This Limited Warranty gives you specific rights. You may also have other rights that vary from state to state. For example, some states do not allow limitations of how long an implied warranty lasts and /or do not allow the exclusion or limitation of incidental or consequential damages, so the limitations and exclusions herein may not apply to you.

© Quadratec, Inc. 2019. All Rights Reserved. 1.30.19 A4 Version

Part #12999.3125



The Trusted Source