

## \*\*\*REFERENCE THE ILLUSTRATION ABOVE WITH THE CHART BELOW FOR PART-SPECIFIC DIMENSIONS\*\*\*

		PHYSICAL DIMENSIONS							HOLE DIMENSIONS			
	BRUSH GUARD	Α	В	С	D	E	HEIGHT <sup>c</sup>	DEPTH <sup>c</sup>	1	2	3	4
PRE-RUNNER	59000 <sup>a</sup>	49	43	20	26	2 9/16	14 1/4	2 9/16	44 1/2	N/A	21 1/2	1 1/16
	59010	46 5/16	40 5/16	19 1/8	29 1/8	5 3/4	12 3/8	9 9/16	41 13/16	27 5/8	20 5/8	4
	59011	47 3/8	41 3/8	19 1/8	29 1/8	3 1/8	12 3/8	7	42 7/8	27 5/8	20 5/8	1 3/8
	59012 <sup>b</sup>	N/A	N/A	19 1/8	29 1/8	2	12 3/8	5 7/8	N/A	27 5/8	20 5/8	N/A
STINGER	59015	46 5/16	40 5/16	19 1/8	29 1/8	5 3/4	18 1/8	11 3/4	41 13/16	27 5/8	20 5/8	4
	59016	47 3/8	41 3/8	19 1/8	29 1/8	3 1/8	18 1/8	9 1/8	42 7/8	27 5/8	20 5/8	1 3/8
	59017 <sup>b</sup>	N/A	N/A	19 1/8	29 1/8	2	18 1/8	8	N/A	27 5/8	20 5/8	N/A

a The center mounting brackets for the 59000 are identical to the outer mounting brackets shown below. There are a total of four (4) mounting holes instead of six (6). The tolerance on 59000 dimensions is ± 1/2".

b 59012 AND 59017 are Center Hoop only configurations with the two center mounting brackets positioned as shown in the figure below.

c Height is measured from the mouting surface to the highest point of the Brush Guard. Depth is measured from the rear mounting bracket to the front-most point of the Brush Guard. Due to manufacturing varitions, the Height and Depth dimensions are approximate and may vary slightly.