




Quick Start Guide

Getting Started

1. Enable Bluetooth on your phone and ensure preferences, sharing, and location services are enabled.
2. Connect the device to your vehicle's OBDII port and turn the ignition to the run position (or engage run mode for push-button start vehicles).



3. Open the app and allow flashcal+ to find and connect to nearby devices.
4. Navigate through the feature screens, then select "Create an Account" and enter your information, or log in if you already have an account.
5. Verify your VIN when it is displayed on the screen.
6. Go to "Home" > "Vehicle Options" > select the desired parameter to modify. The app will prompt you to download custom files for your vehicle.
7. After you've made your adjustment, select "Upload to Vehicle".
8. Once the process is complete, you can start and enjoy driving your vehicle.

LED Indicators

- Fuchsia (solid): Updating Wi-Fi/BLE chip
- Green (solid): USB in use
- Yellow (flashing): PredatorX device's OS is updating
- Blue (flashing): BLE is discoverable
- Blue (solid): BLE is connected
- Red (flashing): Error
- Orange (flashing): Programming ECU or TCU

Contact Information

For operating instructions or trouble shooting, please refer to the flashcal+ tab on our website at www.superchips.com. For any additional questions, please contact:

- Phone: 888-227-2447 (M-F 8AM-5PM EST)
- Email: tech@superchips.com