



## SHERPA BACKPACK

OUTBACK ADVENTURE SMART STORAGE

### INSTALLATION INSTRUCTIONS

The SHERPA Backpack goes at the back of the seat below the headrest. The headrest is installed on the seat back with two rods that go in sockets in the seat back.

The rods have adjustment notches allowing the headrest to be positioned securely at several heights, and there are pushbuttons on the top of the seat back that release the headrest. By depressing the buttons on both sides simultaneously, the headrest can be removed. Removing the headrest and reinstalling it with the rods passing through rings or grommets in the Backpack bag allows the bag to be secured to the seat back.



Use a leather panel with grommets for the rods to pass through; the panel would have fasteners for attaching the bag – when the bag is removed the panel would stay in place on the seat.



## SHERPA BACKPACK

OUTBACK ADVENTURE SMART STORAGE

### CARE INSTRUCTIONS

The SHERPA Backpack is made from heavy cotton duck canvas fabric and leather and is designed to give years of service on the road and trail. Canvas is very easy to clean and handle - a soft and dry bristled brush can be used to remove any loose dust or dirt.

If the canvas needs further cleaning, mix clean water and a small amount of mild detergent and use a damp towel or bristled brush dipped in the solution and scrub or rub the dirty areas gently. Lightly spray the canvas area with water to remove the soap residue and dry with a towel.

To keep the SHERPA Backpack looking new longer, we recommend treating the fabric with Scotchgard Auto Fabric & Carpet Protector. Scotchgard provides excellent resistance to water, oil and stains and it doesn't change the look and feel of the fabric, so the fabric stays soft and colors stay true. Scotchgard comes in an easy-to-use spray bottle.

Note: Do not Dry-Clean, bleach or put in the dryer as these may potentially discolor the canvas or leather.

