



JK Brawler™ Front Bumpers

IMPORTANT: Thank you for purchasing this Poison Spyder product. Please read through this entire document before proceeding with installation. If you are not confident in your mechanical skills, please seek the help of a professional to perform the installation. Check your packages immediately upon arrival to ensure that everything listed is included, and to check for damage during shipping. If anything is missing or damaged, or if you need technical assistance with any aspect of this installation, call Poison Spyder at (951) 849-5911 as soon as possible. This document last updated September 2015.

APPLICATIONS

These installation instructions apply to the following Poison Spyder products:



- 17-59-010-B** JK Brawler Lite Front Bumper - Brawler Bar - Plate Gussets
- 17-59-010-BT** JK Brawler Lite Front Bumper - Brawler Bar - Tube Gussets
- 17-59-010-D** JK Brawler Lite Front Bumper - Tabs
- 17-59-010-DB** JK Brawler Lite Front Bumper - Brawler Bar - Plate Gussets - Tabs (shown above)
- 17-59-010-DBT** JK Brawler Lite Front Bumper - Brawler Bar - Tube Gussets - Tabs
- 17-59-010-DST** JK Brawler Lite Front Bumper - Trail Stinger - Tabs
- 17-59-010-ST** JK Brawler Lite Front Bumper - Trail Stinger



- 17-63-010** JK Brawler MID Front Bumper
- 17-63-010-BT** JK Brawler MID Front Bumper - Brawler Bar
- 17-63-010-D** JK Brawler MID Front Bumper - Tabs
- 17-63-010-DBT** JK Brawler MID Front Bumper - Brawler Bar - Tabs (shown above)



- 17-64-020-BT** JK Brawler FULL Width Front Bumper - Brawler Bar
- 17-64-020-DBT** JK Brawler FULL Width Front Bumper - Brawler Bar - Tabs (shown above)

PARTS LIST

Please check your packages immediately upon arrival to ensure that everything listed is included, and to check for damage during shipping. If anything is missing or damaged, call Poison Spyder at (951) 849-5911 as soon as possible.

- (1) JK Brawler™ Front Bumper
- (1) JK Brawler™ Front Bumper Hardware Kit
PN: HWKIT-17-59-010 Includes:
 - (8) 1/2-13 nylon insert lock nut
 - (8) 1/2 flat washer

TOOLS NEEDED

- Ratchet with 6" socket extension, 19mm deep socket and 3/4" deep socket
- Torque wrench (ft./lbs.)
- 7/32" hex key
- Dead blow hammer or rubber mallet
- Phillips & flat head screwdrivers
- Removal tool for push-in retainer clips or small pry bar

BEFORE YOU BEGIN

The JK Brawler™ Front Bumpers and associated components are shipped un-painted. Before you paint or powder coat, perform the entire installation of the product to ensure that it fits without risking damage to your paint or powder coat finish. Poison Spyder Customs is not responsible for paint or powder coat

costs in the event you damage the finish during installation, or that the parts are incorrect or defective.

You will want to paint or powder-coat these components prior to FINAL installation. If painting them yourself, we recommend starting with a quality etching primer and allowing sufficient cure/dry time between coats and before you apply color. Quality spray-can paints are fine, however be sure to thoroughly paint all of the inside corners and hard-to-reach areas of the bumper. A little extra time and attention to detail on your preparation and paint process will pay off in longer-lasting good looks and rust prevention.

INSTALLATION PROCEDURE

- 1. Park vehicle on a level** surface and set the emergency brake. You will want to wear eye protection beyond this point.
- 2. Remove the plastic lower air dam.** Use a push-in retainer removal tool to pop out the plastic push-in retainers along the front edge and also underneath/behind the air dam where it attaches to the crash bar. If you do not have a push-in retainer tool, a flat-edge screwdriver or small pry-bar may be used.



- 3. If your Jeep is equipped** with factory fog lamps, reach behind the bumper and disconnect the wiring harness plugs from the sockets at the back of each lamp. A small flat head screwdriver may be useful to release the tangs on the plug
- 4. Use a ratchet and 19mm** deep socket to remove the eight (8) nuts that fasten the bumper to the frame. There are two of these nuts on the inner side, and two on the outer side, of each frame rail where it joins the bumper.



With these nuts removed, remove the bumper from the Jeep.



- 5. If your Jeep is equipped** with factory fog lamps, these may be removed from the stock bumper and re-installed into the Brawler Lite bumper. Use a Phillips screwdriver to remove the four (4) retaining screws from each lamp, on the back side of the bumper.



Install the factory fog lamps into the fog lamp mounts in the back side of the Brawler™ Front bumper. Re-use the OE retaining screws. These sheetmetal screws will form their own threads as you drive them into the retaining rings on the Brawler bumper, so press firmly as you twist the screwdriver.



- 6. Remove the plastic top bumper cover.** You may be able to remove the two plastic screws with a Phillips screwdriver. But it is likely they're "frozen" in place and will have to be pried up with the push-in retainer removal tool.



IMPORTANT: If installing the optional Skid Plate, refer at this point to the instructions that came with the Skid Plate, and proceed with those steps. Return to these instructions and proceed with the next step, below, once the Skid Plate installation instructions have been completed.

- 7. Install the Bumper onto the frame.** There are eight (8) threaded studs located on the inside/backside of the bumper, which will correspond with the bumper mounting holes on the frame. It may be a tight fit due to slight manufacturing variances from Jeep to Jeep, but the bumper will fit with some gentle persuasion. You may need to use a rubber mallet or soft dead-blow hammer to tap the bumper into place. Be careful not to mar your paint or powdercoat finish.
- 8. Locate the 1/2-13 nylon insert lock nuts and 1/2" flat washers** that came with your bumper (usually these are shipped threaded onto the studs). Install a flat washer and lock nut onto each of the eight bumper mounting studs at the outside and inside of the frame rail on either side of the Jeep. Snug these with the 3/4" deep socket, extension and ratchet. Torque these nuts to 70 ft.-lbs.



- 9. If you installed the OE fog lamps** into the Brawler bumper, plug the harness connectors back into the sockets in the back of each lamp. Use the OE wire harness push-in retainers to secure the harness to the three (3) provided holes on a flange at the inside rear of the Brawler Lite bumper. You may have to locate them by feel as the area is hard to see once the bumper is installed.

Congratulations, you have completed the installation of your Poison Spyder JK Brawler™ Front Bumper!