



# Quadratec® Deluxe Hardtop Storage Cart

Installation Manual: for '76-'06 CJ-7, Wrangler YJ & TJ Hardtops  
#12020.300



## PARTS LIST:

- (A) Center Section
- (B) Right Leg
- (C) Left Leg
- (D) Z Bracket
- (E) Z Bracket Pad
- (F) End Blocks (2)
- (G) Caster Wheels (4)

## HARDWARE:

- (H) 1/4" X 2" Lag Bolts (8)
- (I) 1/4" X 2.25" Bolts (8)
- (J) 1/4" X 1.5" Bolts (4)
- (K) 1/4" Nylock Nuts (12)
- (L) 1/4" Flat Washers (32)
- (M) #8 X 3/4" Wood Screws (4)

## REQUIRED TOOLS:

- Safety Glasses
- 7/16" Wrench
- 7/16" Socket
- Ratchet Driver
- Flat Blade Screwdriver

### ⚠ CAUTION ⚠

READ ALL SAFETY MESSAGES AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING TO INSTALL THIS PRODUCT. ALWAYS WEAR SAFETY GLASSES DURING INSTALL.

### ⚠ CAUTION ⚠


HARDTOPS ARE HEAVY AND AWKWARD TO HANDLE. WHEN LIFTING THE TOP ONTO THE CART, THE HELP OF 1 OR 2 OTHER PEOPLE IS REQUIRED. DO NOT ATTEMPT TO LIFT WITHOUT HELP.

Visit this product page @ [quadratec.com](http://quadratec.com)  
for a helpful assembly video.



The Trusted Source

**Assembly Instructions:**



*Put on safety glasses. Place the right leg (B) of the cart underneath the center section (A) as shown. Make sure that the square cut end is underneath the center section and the angle cut end is facing out as shown.*


*Install (4) of the 1/4" x 2.25" bolts with (4) washers through the bottom of the caster and up through the right cart leg and center section.*

**NOTICE**

**ALL OF THE WOOD PIECES ARE PRE DRILLED, AND DO NOT REQUIRE DRILLING. HOWEVER, IT MAY BE DIFFICULT TO FIND THE HOLES DUE TO THE CARPETING.**



*ON the opposite side of the cart (top) install (4) more washers and (4) nylock nuts. Tighten the bolts and nuts with a 7/16" socket/ratchet and a 7/16" wrench.*



*Repeat these steps on the left hand side. The angle cut ends of the cart legs should be parallel to each other as shown in the picture above.*



**The Trusted Source**

**Assembly Instructions:**



*Install (4) lag bolts and washers through the bottom of a caster and through the right leg and thread them into one of the end blocks. Please note that the end blocks are only predrilled on one side,*



*this side should be facing down in order to properly install the lag bolts.*

*Tighten with a 7/16" socket.*



*Repeat steps on the left hand side. The cart should look like picture above after this step.*



*Locate the Z bracket and Z bracket pad as shown. The Quadrtec logo should be facing out on the Z bracket. Once again please note that the Z bracket pad is only drilled on one side. Make sure the drilled holes are facing down.*



*Using a flat blade screw driver, install the 4 wood screws through the bottom of the Z bracket and into the Z bracket pad.*



**The Trusted Source**


**Assembly Instructions:**



*Place the Z bracket as shown on the center section of the cart. The Quadratec logo should be facing out. Install (4) 1.5" bolts and washers through the top of the Z bracket and through the cart.*




*Install (4) Nylock nuts and washers on the bottom of the cart and tighten the bolts and nuts with a 7/16" socket/ratchet and a 7/16" wrench.*



**Factory Hardtop  
Default Position**

*The Z bracket has slotted mounting holes in order to accommodate various Hard top designs. The bracket should be moved all the way towards the center of the cart for the default position. This should fit most factory tops.*



**Aftermarket  
Hardtop Position**

*Some aftermarket tops may require the bracket slid to the back of the cart, as shown above.*



**The Trusted Source**

**Care and Use Instructions:**



*Assembled cart top view.*



*Assembled cart bottom view.*



***The cart is ready for use.***

*Hardtops are heavy and awkward to handle. The help of 1 or 2 other people is required. Before placing your hardtop on the storage cart make sure that the rear liftgate window is closed and secured. We highly recommend using as a liftgate locking rod, Part #12020.351 (sold separately).*

*Place the Hardtop on the cart as shown with the bottom corners of the top resting against the inside of the end blocks (yellow arrow) and the upper end of the top resting against the Z bracket pad (red arrow).*

*Make sure the Hardtop is centered on the cart and that the rear window is not directly contacting the cart.*

**NOTICE**

**PLEASE NOTE THAT THIS CART IS A WOODEN PRODUCT AND IS NOT INTENDED FOR USE OUTSIDE OR IN WET LOCATIONS.**



**The Trusted Source**

# Quadrtec® Exclusive Three Year Limited Warranty

Your Quadrtec® branded accessories are covered by the following **Limited Warranty** provided exclusively by Quadrtec, Inc., 1028 Saunders Lane, West Chester PA 19380.

This **Limited Warranty** is the only warranty made in connection with your purchase. Quadrtec neither assumes nor authorizes any vendor, retailer or other person or entity to assume for it any other obligation or liability in connection with this product or **Limited Warranty**. This **Limited Warranty** does not apply and is not cumulative to any accessory or part distributed by Quadrtec for which the Manufacturer provides a separate written warranty.

**What is Covered:** Subject to the terms, exclusions and limitations herein and with respect only to Quadrtec branded accessories first sold in the United States, Quadrtec warrants to the initial retail purchaser only that your Quadrtec accessory shall be free of defects in material and workmanship: **for a period of three (3) years from date of retail purchase.**

This **Limited Warranty** is not assignable and shall terminate upon sale of the vehicle upon which the Quadrtec accessory is installed or other transfer third persons.

All other warranties are hereby disclaimed, except to the extent prohibited by applicable law in which case any implied warranty of merchantability or fitness for a particular purpose on this product is limited to 3 year from date of initial retail sale. Quadrtec reserves the rights to: (a.) require invoice or other proof your accessory is within the terms of this **Limited Warranty** as a condition of warranty service and, (b.) make future revisions to this product and **Limited Warranty** without prior notice or obligation to upgrade your product.

**What is Not Covered:**  
Your Quadrtec **Limited Warranty** does not cover products or parts Quadrtec determines to have been damaged by or subjected to:

(a.) installation damage, alteration, modification, combination with other parts, failure to maintain or improper repair or service, (b.) normal wear & tear, cosmetic damage or damage from moisture or water immersion, (c.) Acts of God, accidents, misuse, negligence, inadequate mounting or impact with vehicle(s), obstacles or other aspects of the environment, (d.) theft, vandalism or other intentional damage.

**Remedy Limited to Repair/Replacement:**  
**The exclusive remedy provided hereunder shall, upon Quadrtec inspection and at Quadrtec's option, be either repair or replacement of product or parts (new or refurbished) covered under this Limited Warranty.** Customers requesting warranty consideration should first contact Quadrtec to obtain a RGA number (610-701-3336). All labor, removal, shipping and installation costs are customer's responsibility.

**Other Limitations - Exclusion of Damages - Your Rights Under State Law:**

In consideration of the purchase price paid, neither Quadrtec nor any independent Quadrtec distributor/licensee are responsible for any time loss, rental costs, or for any incidental, consequential, punitive or other damages you may have or incur in connection with any part or product purchased. Your exclusive remedy hereunder for covered parts is repair/replacement as described above.

This **Limited Warranty** gives you specific rights. You may also have other rights that vary from state to state. For example, some states do not allow limitations of how long an implied warranty lasts and /or do not allow the exclusion or limitation of incidental or consequential damages, so the limitations and exclusions herein may not apply to you.

©Quadrtec, Inc. 2018. All Rights Reserved.  
4.6.18 LTR Version Part #12999.3097



**The Trusted Source**