



SUPERLIFT SUSPENSION SYSTEMS
300 Huey Lenard Loop Rd.
West Monroe, Louisiana 71292
Phone: (318) 397-3000
Sales / Tech: 1-800-551-4955
FAX: (318) 397-3040
www.superlift.com

Superlift® Rear / Lower Rockrunner Link Arms for 2007- newer
JEEP WRANGLER (JK) 4WD and 2WD
INSTALLATION INSTRUCTIONS

INTRODUCTION

Installation requires a professional mechanic. Prior to beginning, inspect the vehicles steering, driveline, and brake systems, paying close attention to the suspension link arms and bushings, anti-sway bars and bushings, tie rod ends, pitman arm, ball joints and wheel bearings. Also check the steering sector-to-frame and all suspension-to-frame attaching points for stress cracks. The overall vehicle must be in excellent working condition; repair or replace all worn parts.

Read instructions several times before starting. Be sure you have all needed parts and know where they install. Read each step completely as you go.

NOTES:

- These link arms should be installed only on JK vehicles equipped with a 3" to 4" suspension lift.
• It is extremely important for the Rockrunner link arms to be adequately greased. Grease should be added at minimum during every oil change, plus after every trip off-road, to ensure the arms remain free of dirt, water and other contaminants.
• A foot-pound torque specification is given in parenthesis () after each appropriate fastener.
• Prior to attaching components, be sure mating surfaces are free of grit, grease, excessive undercoating, etc.
• A factory service manual should be on hand for reference.
• Use the check-off box "☐" found at each step to help you keep your place. Two boxes "☐☐" denotes that one check-off box is for the driver side and one is for the passenger side.

PARTS LIST ... The part number is stamped into each part or printed on an adhesive label. Identify each part and place the appropriate mounting hardware with it.

Table with 3 columns: PART NO., DESCRIPTION (Qty.- if more than one), NEW ATTACHING HARDWARE (Qty.). Rows include part 66-01-5722 (link arm) and part 00421 (decals).

INSTALLATION PROCEDURE

NOTE: Save all factory components and hardware for reuse, unless noted.

1) PREPARE VEHICLE...

- ☐ Place vehicle in low gear or park. With the suspension supporting vehicle weight, and the

vehicle on level ground, use an inclinometer to take a rear driveshaft angle reading. This reading will be needed if a driveline vibration exists after installation.

Prior to raising the vehicle, detach the axle end of the track bar then tie the bar up and out of the way.

Place vehicle in neutral. Raise the rear of the vehicle with a jack and secure a jack stand beneath each frame rail, just in front of the brackets for the lower link arms. Ease the frame down onto the stands, place transmission in low gear or "park", and chock front tires. Remove rear tires.

2) ROCKRUNNER LINK ARM PREPARATION...

Each link arm's axle end requires a 2-piece Urethane bushing and inner wear sleeve. Thoroughly lubricate all bushing and sleeve bearing surfaces with a light, Silicone or Lithium-based grease then install them into the link arm eyes.

Grease fittings - The threaded swivel end of the Rockrunner link arm attaches to the frame; install this 90-degree grease fitting so that it points rearward or inboard. On the link arm's opposite (axle) end, install this 90-degree grease fitting so, when on the vehicle, it points forward.

Rockrunner link arm length, measured from center of eye-to-center of eye, must measure 19-11/16"; verify that both arms are set to this length. If adjustment is necessary, rotate the threaded swivel end accordingly. Consider grease fitting orientation when setting link arm length.

3) ROCKRUNNER LINK ARM INSTALLATION...

Position a jack under the center of the rear axle and raise it enough so that it supports, but does not raise, the axle assembly.

NOTE: Perform the remaining steps in step 3 one side at a time.

Remove the factory lower / rear link arm.


Attach the threaded swivel end of the Rockrunner link arm-to-frame using the factory hardware; install the bolt from the outside. Verify that the grease fitting is on top and oriented towards the inboard or rear of the vehicle. Do not tighten the link arm bolt yet.

Attach the opposite end of the Rockrunner link arm-to-axle using factory hardware. The grease fitting should be on bottom of the arm. Do not tighten the link arm bolt yet.

4) TIRES / WHEELS... [DIAGRAM 1]

Tighten the lug nuts (115) in the sequence shown.

WARNING: When the tires / wheels are installed, always check for and remove any corrosion, dirt, or foreign material on the wheel mounting surface, or anything that contacts the wheel mounting surface (hub, rotor, etc.). Installing wheels without the proper metal-to-metal contact at the wheel mounting surfaces can cause the lug nuts to loosen and the wheel to come off while the vehicle is in motion.



WARNING: Retighten lug nuts at 500 miles after any wheel change, or anytime the lug nuts are loosened. Failure to do so could cause wheels to come off while vehicle is in motion.

Lower vehicle to the floor. The suspension is now supporting vehicle weight.

5) **HARDWARE TIGHTENING SEQUENCE...**

Reattach the lower end of the track bar-to-axle using the factory hardware (125).

Tighten the axle and frame link arm bolts (130).

6) **LUBRICATE the ROCKRUNNER LINK ARMS...** Lubricate all grease fittings until grease is barely visible around the bushings and pivot points. Lubricate the arms at every oil change and after every off-road trip.

7) **FINAL CLEARANCE and TORQUE CHECK...** With vehicle on floor, inspect the tires / wheels, suspension and brake systems for proper operation, tightness, and adequate clearance.

8) **DRIVESHAFT ANGLE... procedure for trouble-shooting a driveshaft angle related driveline vibration:** Use an inclinometer to take a rear driveshaft angle reading and compare this to the reading taken in step 1. The goal is to get as close to the original angle as possible. To adjust driveline angle, unbolt the threaded swivel ends of the link arms, one side at a time, and lengthen or shorten them accordingly: To reduce vibration under acceleration, lengthen the arms, which moves the axle pinion downward. To reduce vibration under deceleration, shorten the arms, which rotates the pinion upward. It is crucial that both arms are adjusted the same amount so that arm length and vehicle wheelbase remains equal.

IMPORTANT: Do not adjust the link arms more than 3 full revolutions from their initial set running length of 19-11/16".

Important Maintenance Information

It is the ultimate buyer's responsibility to have all bolts / nuts checked for tightness after the first 100 miles and then every 1000 miles. The steering, suspension and driveline systems, plus wheel alignment should be inspected by a qualified professional mechanic at least every 3000 miles.

Limited Lifetime Warranty / Warnings

Your Superlift® product is covered by the Limited Warranty explained below that gives you specific legal rights. This limited warranty is the only warranty Superlift® makes in connection with your product purchase. Superlift® neither assumes nor authorizes any retailer or other person or entity to assume for it any other obligation or liability in connection with this product or limited warranty.

What is covered? Subject to the terms below, Superlift® will repair or replace its products found defective in materials or workmanship for so long as the original purchaser owns the vehicle on which the product was originally installed. Your warrantor is LKI Enterprises, Inc. d/b/a Superlift® Suspension Systems ("Superlift®").

What is not covered? Your Superlift® Limited Warranty does not cover products, parts or vehicles Superlift® determines to have been damaged by or subjected to:

- Alteration, modification or failure to maintain.
- Normal wear and tear (bushings, tie-rod ends, etc.). Scratches or defects in product finishes (powder coating, plating, etc.),
- Damage to or resulting from vehicle's electronic stability system, related components or

- other vehicle systems.
- Racing or other vehicle competitions or contests. Accidents, impact by rocks, trees, obstacles or other aspects of the environment.
 - Theft, vandalism or other intentional damage.

Remedy Limited to Repair / Replacement. The exclusive remedy provided hereunder shall, upon Superlift's inspection and at Superlift's option, be either repair or replacement of product or parts covered under this Limited Warranty. Customers requesting warranty consideration should contact Superlift® by phone (1-800-551-4955) to obtain a Returned Goods Authorization number. All removal, shipping and installation costs are customer's responsibility.

If a replacement part is needed before the Superlift® part in question can be returned, you must first purchase the replacement part. Then, if the part in question is deemed warrantable, you will be credited / refunded.

Other Limitations - Exclusion of Damages - Your Rights Under State Law

- Neither Superlift® nor your independent Superlift® dealer are responsible for any time loss, rental costs, or for any incidental, consequential or other damages you may have.
- This Limited Warranty gives you specific rights. You may also have other rights that vary from state to state. For example, while all implied warranties are disclaimed herein, any implied warranty required by law is limited to the terms of our Limited Lifetime Warranty as described above. Some states do not allow limitations of how long an implied warranty lasts and / or do not allow the exclusion or limitation of incidental or consequential damages, so the limitations and exclusions herein may not apply to you.

Important Product Use and Safety Information / Warnings

As a general rule, the taller a vehicle is, the easier it will roll over. Offset, as much as possible, what is lost in rollover resistance by increasing tire track width. In other words, go "wide" as you go "tall". Many sportsmen remove their mud tires after hunting season and install ones more appropriate for street driving; always use as wide a tire and wheel combination as feasible to enhance vehicle stability. We strongly recommend, because of rollover possibility, that the vehicle be equipped with a functional roll bar and cage system. Seat belts and shoulder harnesses should be worn at all times. Avoid situations where a side rollover may occur.

Generally, braking performance and capabilities are decreased when significantly larger / heavier tires and wheels are used. Take this into consideration while driving. Also, changing axle gear ratios or using tires that are taller or shorter than factory height will cause an erroneous speedometer reading. On vehicles equipped with an electronic speedometer, the speed signal impacts other important functions as well. Speedometer recalibration for both mechanical and electronic types is highly recommended.

Do not add, alter, or fabricate any factory or aftermarket parts to increase vehicle height over the intended height of the Superlift® product purchased. Mixing component brands is not recommended.