



advanced FLOW engineering

Instruction Manual P/N: 51-12662/ 54-12662

Make: **Jeep** Model: **Grand Cherokee SRT-8** Year: **12-15** Engine: **V8-6.4L Hemi**



- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- If you are missing any of the components, call customer support at 951-493-7100.
- Ensure you have all necessary tools before proceeding.
- Do not attempt to work on your vehicle when the engine is hot.
- Disconnect the negative battery terminal before proceeding.
- Retain factory parts for future use.

Label	Qty.	Description	Part Number
A1	1	Pro DRY S Air Filter	21-91018 (Gray Media) (51-12662)
A2	1	Pro 5R Air Filter	24-91018 (Blue Media) (54-12662)
B	1	Tube	05-12662B1
C	1	Housing	05-12662B2
D	1	Adaptor	05-00611
E	1	3-1/2 Silicone Coupling	05-01264
F	1	3-7/8 Silicone Coupling	05-01314
G	2	Clamp #60	03-50002
H	2	Clamp #56	03-50009
I	1	Grommet	03-50050
J	1	Seal Trim (20.5")	05-00072
K	1	Seal Trim (5.5")	05-00072
L	5	Screw, Button Head	03-50102
M	1	Hose, Vent 5/8" (8")	05-00069

Tools Needed:

8mm Nut Driver, 4mm allen hex key, 10mm wrench

Note: Legal in California for use on race vehicles only. The use of this device on vehicles used on public streets or highways is strictly prohibited in California and others states that have adopted California emission regulations.





Figure A

Refer to Figure A for Step 1

Step 1: Remove oil cap and cover trim. ①



Figure B

Refer to Figure B for Steps 2-4

Step 2: Disconnect the temp sensor harness from the OE intake. ②

Step 3: Loosen the throttle body clamp on the OE intake from the engine using an 8mm nut driver.

Step 4: Disconnect the engine vent hose from the OE housing and valve cover.

**Figure C****Refer to Figure C for Steps 5-8**

Step 5: Remove the OE intake tube. Remove the filter housing by pulling straight up. Remove the plastic panel below the housing. Detach the wire clip if present.

Step 6: Remove the temp sensor from the OE intake by turning the sensor counter clockwise. (Be sure not to damage the sensor).

Step 7: Place the provided grommet on the aFe intake tube.

Step 8: Install the temp sensor in the aFe intake tube through the rubber grommet. It may be easier to remove the sensor o-ring



Refer to Figure D for Steps 9-13

Step 9: Pre-assemble the aFe housing. Remove the grommets located in the lower portion of the OE air box and place on the aFe housing.

Step 10: Install the injection molded filter adaptor to the aFe housing. use the M6 screws, then tighten down with a 4mm allen hex key. ④

Step 11: Pre-assemble the larger coupler and secure by using the clamps provided. **DO NOT TIGHTEN**

Step 12: Install the aFe air filter to the adaptor using an 8mm nut driver

Step 13: Install trim seal around the top edges of the aFe housing.




Figure E

Refer to Figure E for Steps 14-19

Step 14: Install the housing and secure with OE screw near the washer fill tube.

Step 15: Loosely place clamps on the smaller coupling and place on the throttle body. DO NOT TIGHTEN DOWN.

Step 16: Install the aFe intake tube. Adjust the couplings for the best fitment. Be sure the tube aligns perfectly with the throttle body.

Step 17: Tighten down all clamps using an 8mm nut driver.

Step 18: Re-connect the temp sensor. ⑤

Step 19: Connect the 8" vent hose to the aFe intake tube and valve cover. the vent hose is a tight fit on the valve cover fitting. It will help to use a lubricant and small screwdriver. ⑥



Figure F

Refer to Figure F for Steps 20-21

Step 20: Reinstall cover trim and oil cap.

Step 21: Your installation is now complete. Enjoy!

*Verify all connections are secure 100-200 miles after installation



Pro DRY S Air Filter



P/N: 21-91018

Pro 5R Air Filter



P/N: 24-91018

Gold Aerosol Restore Kit



P/N: 90-50000

Pro DRY S Restore Kit



P/N: 90-59999

Blue Squeeze Restore Kit



P/N: 90-50501

Blue Aerosol Restore Kit



P/N: 90-50001

aFe Flashlight



P/N: 40-10131

aFe Power Hat



P/N: 40-10083

Gold Squeeze Restore Kit



P/N: 90-50500

To purchase any of the items above, view airflow charts, dyno graphs, photos, and video; please go to aFepower.com.

Warranty

General Terms:

- aFe warrants their products to be free from manufacturer's defects due to workmanship and material.
- This warranty applies only to the original purchaser of the product and is non-transferrable.
- Proof of purchase of the aFe product is required for all warranty claims.
- Warranty is valid provided aFe instructions for installation and/or cleaning were properly followed.
- Proper maintenance with regular inspections of product is required to insure warranty coverage.
- Damage due to improper installation, abuse, unauthorized repair or alteration is not warranted.
- Incidental or consequential damages or cost, including installation and removal of part, incurred due to failure of aFe product is not covered under this warranty.
- All warranty is limited to the repair and/or replacement of the aFe part. To request Return Goods Authorization ("RGA"), email RGA@afepower.com or call (951)493-7100. Upon receipt of the RGA, you must return the product to the address provided in the RGA, freight prepaid and accompanied with a dated proof of purchase and the RGA. Upon receipt of the defective product and upon verification of proof of purchase, aFe will either repair or replace the defective product within a reasonable time, not to exceed thirty days.

Product Category	P/N Prefix	Warranty duration
Direct OE Replacement Filters	10, 11, 30, 31, 71, 73	Life of the vehicle
Racing Filters	18	1 year
Universal	21, 24, 72	2 years
Air Intake Systems	50, 51, 54, 55, 75	2 years
Exhaust Systems	49	2 years
Intercoolers & Intercooler Tubes	46-2	2 years
Intake Manifolds	46-1	2 years
Differential Cover	46-7	Life of the vehicle
Exhaust Manifolds	46	2 years
Throttle Body Spacers	46-3	2 years
Fluid Filters	44	90 days
Pre-Filters	28	2 years
Heavy Duty OE Replacement	70	2 years
PowerSports OE Replacement	81, 87	2 years
PowerSports Intake Systems	85	2 years

No other warranty expressed or implied applies nor is any person or advanced FLOW engineering authorized to assume any other warranty. Some States do not allow the exclusion or limitation of incidental or consequential damages or do not allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from State to State.



advanced FLOW engineering, inc.
252 Granite Street Corona, CA 92879
TEL: 951.493.7100 • TECH: 951.493.7100 x23
E-Mail: Tech@aFepower.com