



97-06 JEEP TJ 7" FLARE KIT

Thank you for choosing Rough Country for all your suspension needs.

Please read instructions before beginning installation. Check the kit hardware against the parts list on this page. Be sure you have all needed parts and know where they go. Also please review tools needed list and make sure you have needed tools.

Kit Contents:

Rear Driver Flare
Rear Pass Flare
Front Driver Flare
Front Driver Lower Flare
Front Pass Flare
Front Pass Lower Flare
1-Hardware Bag





Tools Needed:


Pliers
8MM Socket / Wrench
10mm Socket / Wrench
11MM Socket / Wrench

REAR INSTALLATION INSTRUCTIONS


- Starting on the rear, remove the plastic trim retainer as shown holding the inner fender skirting in place on the front of the rear fender well.
- Remove the plastic debris flap hardware as shown using a 8mm & 11mm socket and remove the flap. Retain hardware.



3. Remove the inner fender wheel well plastic allowing access to the plastic flare retainers. **See Photo 3.**
4. Remove the all hardware securing the stock flare to the body using a 8mm wrench. **See Photo 4.**




5. Remove the stock flare from the Jeep. Locate the appropriate flare and install using the supplied hardware. Tighten using a 8mm wrench. Slightly snug the hardware. Do not over-tighten the hardware. **See Photo 5.**
6. Reinstall the plastic inner fender well with the stock hardware and reinstall the plastic trim retainer. The rear plastic debris flap can be reinstalled if desired. **See Photo 6.**





FRONT INSTALLATION INSTRUCTIONS


1. Remove the front lower leg of the fender flare using a 8mm wrench. **See Photo 1.**
2. Remove the bulb and harness from the front flare lights. **See Photo 2.**



3. Remove all the stock flare hardware using a 8mm wrench. Remove the flare from the vehicle. **See Photo 3.**
4. Remove the stock lens from the flare using a 10mm socket. **See Photo 4.**



5. Reinstall the lens in the appropriate fender flare and tighten using a 10mm wrench.
6. Install the lower leg of the fender flare and tighten using a 8mm wrench. **See Photo 5.** Lightly snug the hardware, do not over-tighten the hardware.
7. Install the new flare on the vehicle using the supplied hardware. **See Photo 6.** Tighten using a 8mm wrench. Lightly snug the hardware, do not over-tighten the hardware.



8. Reinstall the bulb / harness in the flare. See Photo 7.

