



**\*\*\*\*\*THIS INSTALL SHOULD BE DONE BY A PROFESSIONAL\*\*\*\*\***  
**\*\*\*\*\*YOUR VEHICLE WILL REQUIRE AN ALIGNMENT AFTER INSTALL\*\*\*\*\***

**REQUIRED TOOLS**

Jack  
Jack Stands  
Sockets  
Ratchet  
Torque Wrench  
Wrenches  
Tie Rod, Ball Joint Puller

**KIT CONTAINS**

Front Coil Spring Spacer  
Rear Coil Spring Spacer

**QTY**

2  
2



### Jeep® JK Wrangler 1.75" Lift Kit

#### BEFORE INSTALLATION:

Check all parts to make sure you have a complete kit.

Inspect all steering and suspension parts before installing your kit. Worn or damaged parts could fail after install of your kit. Replace or repair any worn or damaged parts.

#### INSTALLATION:

- 1) On a smooth, flat, and hard surface. Block your tires and set the emergency brake.
- 2) Jack your vehicle up and set on jack stands.
- 3) Remove your front tires and wheels.
- 4) Using a jack support the axle on the side of the Jeep you are working on.
- 5) Remove the shock, unbolt the sway bar from both sides of the vehicle, remove the tie rod end nut and remove the tie rod end from the knuckle. Unbolt brake line bracket from axle.
- 6) Slowly release the jack until the axle drops enough to remove the coil spring. (You might need to unbolt the track bar from the axle to get enough drop).
- 7) Install your Fishbone Coil Spacer over your factory spring isolator.
- 8) With the coil spring installed in the spring pocket slowly raise the axle with your jack.
- 9) Once the axle is raised enough reattach the tie rod end, reinstall front shock, and brake line bracket. (Reinstall track bar into the axle mount if previously removed).
- 10) Repeat on the opposite side.
- 11) Reinstall the sway bar
- 12) Install front tires and wheels.
- 13) Remove your rear tires and wheels.
- 14) Using a jack support the axle on both sides of the Jeep.
- 15) Remove the shocks, unbolt the sway bar end link from both sides of the vehicle, remove the bracket that holds the brake lines to the body.
- 16) Slowly release the jack until the axle drops enough to remove the coil spring.
- 17) Remove the factory spring isolator and install your Fishbone spring spacer.
- 18) With the coil springs installed in the spring pocket slowly raise the axle with your jack.
- 19) Once the axle is raised enough reinstall rear shocks, sway bar end links and brake line brackets.
- 20) Install rear tires and wheels.
- 21) Set vehicle back on the ground.
- 22) Make sure to tighten all bolts to factory torque specifications. Re-torque all bolts after 500 miles.

#### WARNING!!!

This vehicle now has modified suspension. The steering, braking and handling will be different than an unmodified vehicle. Avoid driving conditions that could cause loss of control. You must drive your vehicle carefully! If larger tires are installed your speedometer will read lower than the vehicles actual speed.

#### ENJOY YOUR FISHBONE OFFROAD COIL SPRING SPACERS!!!